

**9700053** Revision 04/24/22

## 22R/RE Billet Flex Fan Spacer Kit - Part #1093012

### **Contents of Kit:**

- 1 Billet Fan Spacer
- 4 M8-1.25 x 16mm Hex Bolts
- 4 M8 Flat Washers

### **Installation Instructions:**

1. Loosen bolts that hold the fan to the water pump.

- a. Do not remove them just loosen them while the belt is still on to make removal easier.
- 2. Remove water pump belt and then remove fan assembly from water pump.
  - a. You can also remove the fan shroud for extra room but this is not necessary.
- 3. Remove stock fan studs in water pump and chase hub threads with a tap.
- 4. Install the flex fan on the fan spacer using M8 Hex Bolts and M8 flat washers.
  - a. Use a mild thread locking compound on bolts.
- 5. Install hub and fan assembley on the water pump flange using the M6 hex bolts and M6 flat washers.
- 6. Rotate engine by hand, checking for fan clearance before starting engine.

2031 Holly Avenue, Lake Havasu City, AZ 86404 Office 928.505.2501 Fax 928.505.2503



**9700053** Revision 04/26/22

# 22R/RE Billet Flex Fan Spacer Kit - Part #1093012

#### **Contents of Kit:**

1 Billet Fan Spacer

4 M6-1.00 x 25mm Hex Bolts4 M6 Flat Washers

4 M6-1.00 x 25mm Hex Bolts

4 M6 Flat Washers

- 4 M8-1.25 x 16mm Hex Bolts
- 4 M8 Flat Washers

#### **Installation Instructions:**

- 1. Loosen bolts that hold the fan to the water pump.
  - a. Do not remove them just loosen them while the belt is still on to make removal easier.
- 2. Remove water pump belt and then remove fan assembly from water pump.
  - b. You can also remove the fan shroud for extra room but this is not necessary.
- 3. Remove stock fan studs in water pump and chase hub threads with a tap.
- 4. Install the flex fan on the fan spacer using M8 Hex Bolts and M8 flat washers.
  - c. Use a mild thread locking compound on bolts.
- 5. Install hub and fan assembley on the water pump flange using the M6 hex bolts and M6 flat washers.
- 6. Rotate engine by hand, checking for fan clearance before starting engine.