**9700073** Revision 04/25/22



## Teflon Heat Dissipation Kit Part #1032090, #1032095, #1032098

LC Engineering's Heat Dissipation kits will install just like an ordinary gasket. These Teflon spacers do not require the use of any silicone or adhesive to install them. The only time you will want to use any silicone is on a water port that has electrolysis damage to fill the porosity. When handled with care these gaskets can be re-used several times as long as it has not been damaged.

2031 Holly Avenue, Lake Havasu City, AZ 86404 Office 928.505.2501 Fax 928.505.2503



**9700073** Revision 04/25/22

## Teflon Heat Dissipation Kit Part #1032090, #1032095, #1032098

LC Engineering's Heat Dissipation kits will install just like an ordinary gasket. These Teflon spacers do not require the use of any silicone or adhesive to install them. The only time you will want to use any silicone is on a water port that has electrolysis damage to fill the porosity. When handled with care these gaskets can be re-used several times as long as it has not been damaged.