

MAGNUSON

SUPERCHARGERS




VF Tuner

Flash Tool Instructions

NOTES

2. Fill out the Calibration File Form 1. Please use accurate information in order to get a faster response. Tool will be licensed within 24 hours (Monday-Friday excluding holidays).



Toyota Tacoma 3.5L Calibration File Form 1

[Switch account](#)

* Required

Email *

Your email

Serial Number on Orange Dongle *

Your answer


3. **Connect your vehicle's battery to a battery charger to ensure that you have at least 12V at all times while following these instructions.**




4. Gather the supplied VF Tuner flash tool.




5. Now go to <https://www.magnusonsuperchargers.com/> and click on the "Support" tab at the top of the page.




6. Click on the “Toyota Flash Tool” which is on the “Support” page. **Note: You will need to turn off any firewall and antivirus programs for these downloads.**




7. Click on “Run”.




8. If you get a “Windows protected your PC” message, click on more info.




9. Click on “Run Anyway”.




10. Select “I accept the agreement” then click “Next”.




11. Click on “Next”.




12. Click on “Next”.




13. Select “Create a desktop shortcut. Click on “Next”.



14. Click on “Finish”.



15. Open the software by double clicking on the software shortcut icon “vF Tuner” on your computer desktop.




Identifying the ECU


16. The following steps require you to connect your vehicle to the laptop through the OBDII Port using the orange dongle. You **MUST** also have internet connection on your laptop.



17. Turn the ignition switch to the on position (**Engine off**). **On Tacoma's / Tundra's with a push button start DO NOT depress the brake pedal and push the start button twice.** Click on Flash ECU icon shown with the arrow.




18. Click on “Prepare ECM” the ID number is your calibration ID. Do not license the vehicle at this point yet. **Calibration ID should look something like ex: 8966304B3100.**




Go to back to **MagnusonSuperchargers.com**


19a. **For Tacoma:**
Under Superchargers → Toyota → Tacoma → Toyota Tacoma 2GR-FKS 3.5L V6 Superchargers System → Manuals, Documents and Calibration. Click on **“Toyota Tacoma 3.5L Calibration File Form 2”**.



19b. **For Tundra:**
Under Superchargers → Toyota → Tundra → 2019 Toyota Tundra 3UR-FE 5.7L V8 Superchargers System → Manuals, Documents and Calibration. Click on **“Toyota Tundra 2019+ Calibration File Form 2”**.




19c. **For 4Runner:**
Under Superchargers → Toyota → 4Runner → TVS1320 4Runner 4.0L Supercharger System → Manuals, Documents and Calibration. Click on **“Toyota 4Runner 4.0L Calibration File Form 2”**.




20. Fill out the Calibration File Form 2. Please use accurate information in order to get a faster response. *Magnuson Superchargers will send back a calibration file within 24 hours (Monday-Friday excluding holidays).




21. When you receive the new calibration file back, re-connect to the vehicle. (Key on **engine off**). Open the VF tuner software and click on the flash ECU icon. Click on prepare ECU.




22. **Make sure you have a battery charger connected.** Click on “Prepare ECM” Follow on screen prompts.



23. Follow the prompt on screen and click “Select Calibration File”.



24. Click on calibrate ECM and follow the prompts on the screen. Progress bar will be completely green when it is complete



NOTES

If you have any troubles with this process contact our technical support at support@magnusonsuperchargers.com or call 1-805-642-8833 (Press Option 3).



MAGNUSON
SUPERCHARGERS

1990 Knoll Drive, Building A
Ventura, CA, 93003
www.magnusonsuperchargers.com
1.805.642.8833