



9700060 Revision 09/28/23



Axle Breather Relocation Kit – Part # 1020410

This kit will extend the front and rear differential breathers up onto the frame to help prevent water and contaminants from entering your axles. This is vital if you traverse water or mud while out off-roading. The kit comes with axle fittings, hose, and filters for easy installation.

Kit Contents:

- (2) Filters
- (2) Push-Lock Fittings
- (2) AN Fittings
- 5' of 1/4" Hi Pressure Hose

Installation Instructions

1. Remove factory breather fitting from your differential.
2. Install 1/8" to -4 adapter steel fitting. Use thread sealant. Tapered pipe thread installs into differential.
3. Install 45 degree -4 Push-Lock fitting onto adapter. Tighten down as shown in photo.
4. Install 1/4" Push-Lock hose onto fitting. NOTE: Push-Lock hose can be difficult to install. We have found its best to heat the hose end up with a heat gun to make it more pliable and to use a light oil on the fitting to ease install. Hose should bottom out onto the plastic ring.
5. Route the hose upward to the frame in the highest best place suitable. Zip tie into place and install to leave enough slack in the hose to allow for suspension droop. 5' of hose is supplied and its up to you on where to route it and how much to use for front and back.